

### 3.0 WMD Diesel Generator Fast Moving Parts List

| <b>Description</b>         | <b>Part #</b> | <b>Description</b>          | <b>Part #</b> |
|----------------------------|---------------|-----------------------------|---------------|
| Alternator                 | 32939         | Panel, Genset Control       | 32340         |
| Belt, Sea Water Pump       | 32942         | Panel, Remote Stop Start    | 24943         |
| Belt, STD Alternator       | 13585         | Preheat & Start Switch      | 24732         |
| Circuit Breaker            | 24683         | Porn, Fresh Water           | 33197         |
| Rectifier, Bridge          | 43649         | Pump, Mounting Gasket       | 33198         |
| Dipstick                   | 33170         | Pump, Rebuild Kit           | N/A           |
| Emergency Stop Switch      | 33259         | Pump, Sea Water             | 32617         |
| Exhaust Temperature Switch | 32923         | Pump, Mounting Gasket       | N/A           |
| Filter, Lube Oil           | 36918         | Pump, Impeller Kit          | 32620         |
| Filter, Fuel Oil           | 30200         | Pump, Repair Kit            | 40455         |
| Filter, Electric Lift      | 30548         | Pump, Seal                  | 33043         |
| Gasket, Head               | 33162         | Pump, Fuel Lift             | 39275         |
| Gasket, Oil Pan            | 33169         | Rectifier                   | 43649         |
| Gasket Set, Upper          | 33075         | Remote lube Oil Filter      | 32149         |
| Gasket Set, Complete       | 33076         | Silencer, Air Intake        | 32434         |
| Glow Plug                  | 33204         | Solenoid, Fuel Shut Off     | 23041         |
| Harness 15 FT" EXT 8 Pin   | 30760         | Solenoid, Preheat           | 24639         |
| Heat Exchanger             | 36895         | Spare Parts Kit A           | 33077         |
| Heat Exchanger, End Cap    | 33297         | Spare Parts Kit B           | 33078         |
| Heat Exchanger, Gasket     | 33298         | Starter Motor               | 32940         |
| Injector                   | 33157         | Starter Solenoid            | 30245         |
| Injector Pump              | 33181         | Stop Switch                 | 24731         |
| Injection Hardware Kit     | 33079         | Tank, Coolant Recovery      | 24977         |
| Injector Nozzle            | 30297         | Thermostat                  | 24688         |
| Injector Return Line       | 33002         | Thermostat Mounting Gasket  | 32586         |
| Isolators, Front           | 24776         | Valve Cover Gasket          | 33164         |
| Isolators, Rear            | 24776         | Voltmeter                   | 35111         |
| Manual, Operators          | 33105         | Water Temperature Meter     | 37601         |
| Manual, Parts List         | 33404         | Water Temperature Sender    | 35109         |
| Manual, Technical          | 33403         | Water Temperature Switch    | 39550         |
| Oil Pressure Switch        | 37323         | Water In"" Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter         | 35110         | Zinc                        | 11885         |
| Oil Pressure Sender        | 24132         | Manifold, Exhaust           | 37309         |

### 3.8 BCDT Diesel Generator Fast Moving Parts List

| Description                      | Part # | Description                     | Part # |
|----------------------------------|--------|---------------------------------|--------|
| Alternator                       | NA     | Panel, Genset Control           | 46149  |
| Belt, Sea Water Pump             | NA     | Panel, Remote Stop/Start        |        |
| Belt, STD Alternator             | NA     | Preheat & Start Switch          |        |
| Circuit Breaker                  | 50505  | Pump, Fresh Water               |        |
| Battery Charger                  | 46061  | Pump, Mounting Gasket           |        |
| Diode                            |        | Pump, Rebuild Kit               |        |
| Dipstick                         | 45830  | Pump, Sea Water                 | 45765  |
| Electronic Voltage Regulator     |        | Pump, Mounting Gasket           | N/A    |
| Emergency Stop Switch            |        | Pump, Impeller Kit              | 32620  |
| Exhaust Temperature Switch       |        | Gasket, Sea Water Cover         | 45767  |
| Filter Assembly, Lube Oil        | 45823  | Pump, Repair Kit                | 40455  |
| Filter, Fuel (primary on engine) | 44769  | Pump, Seal                      | 33043  |
| Filter, Fuel (secondary in S.G.) | 44770  | Pump, Fuel Lift                 | 45610  |
| Gasket, Head                     | 45849  | Rectifier                       |        |
| Gasket, Oil Pan                  |        | Remote Lube Oil Filter          |        |
| Gasket Set, Upper                |        | Silencer, Air Intake            |        |
| Gasket Set, Complete             | 45825  | Solenoid, Fuel Shut Off         | 45890  |
| Glowplug                         |        | Solenoid, Preheat               |        |
| Harness 15 FT. EXT 8 Pin         |        | Spare Parts Kit A               |        |
| Heat Exchanger                   |        | Spare Parts Kit B               |        |
| Heat Exchanger End Cap           |        | Starter Motor                   | 45782  |
| Heat Exchanger Gasket            |        | Starter Solenoid                |        |
| Injector                         | 45758  | Stop Switch                     |        |
| Injection Pump                   | 45755  | Tank, Coolant Recovery          |        |
| Injection Hardware Kit           |        | Thermostat                      | 45786  |
| Injector Nozzle                  | 45760  | Thermostat Mounting Gasket      | 45833  |
| Injector Return Line             | 45832  | Valve Cover Gasket              | 45834  |
| Isolators, Front                 |        | Voltmeter                       |        |
| Isolators, Rear                  |        | Water Temperature Meter         |        |
| Manual, Owner                    | 44284  | Water Temperature Sender        |        |
| Manual, Parts List               |        | Water Temperature Switch        | 45790  |
| Manual, Technical                |        | Water Injected Exhaust Elbow 45 |        |
| Oil Pressure Switch              | 45611  | Water Injected Exhaust Elbow 90 |        |
| Oil Pressure Meter               |        | Zinc                            |        |
| Oil Pressure Sender              |        | Plug, Welch 18 MM               | 299905 |
|                                  |        | Harness, wiring                 | 46118  |

## 4.0 BCD Diesel Generator Fast Moving Parts List

| <b>Description</b>             | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|--------------------------------|---------------|---------------------------------|---------------|
| Alternator                     |               | Oil Pressure Meter              | 37603         |
| Belt, Sea Water Pump           | 30376         | Oil Pressure Sender             | 24132         |
| Belt, STD Alternator           |               | Panel, Genset Control           | 36539         |
| Circuit Breaker                | 24683         | Panel, Remote Stop/Start        | 24943         |
| Diode                          | 35971         | Preheat & Start Switch          | 24732         |
| Dipstick                       | 37072         | Pump, Fresh Water               | 37015         |
| Electronic Voltage Regulator   | 30257         | Pump, Mounting Gasket           | 36957         |
| Emergency Stop Switch          | 33259         | Pump, Rebuild Kit               | N/A           |
| Exhaust Temperature Switch     | 32923         | Pump, Sea Water                 | 33636         |
| Filter, Lube Oil               | 36918         | Pump, Mounting Gasket           | 30326         |
| Filter, Fuel Oil               | 30200         | Pump, Impeller Kit              | 34440         |
| Filter, Electric Lift          | 30548         | Pump, Repair Kit                | 34466         |
| Gasket, Head                   | 38848         | Pump, Seal                      | 33043         |
| Gasket, Head (B Model)         | 43550         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan                | 36988         | Rectifier                       | 43649         |
| Gasket Set, Upper              | 38352         | Remote Lube Oil Filter          | 40078         |
| Gasket Set, Upper (B Model)    | 43560         | Silencer, Air Intake            | 37191         |
| Gasket Set, Complete           | 38353         | Solenoid, Fuel Shut Off         | 37100         |
| Gasket Set, Complete (B Model) | 43561         | Solenoid, Preheat               | 24639         |
| Glowplug                       | 36961         | Spare Parts Kit A               | 38350         |
| Harness 15 FT. EXT 8 Pin       | 30760         | Spare Parts Kit B               | 38351         |
| Heat Exchanger                 | 38147         | Spare Parts Kit B (B Model)     | 43652         |
| Heat Exchanger End Cap         | 22850         | Starter Motor                   | 34552         |
| Heat Exchanger Gasket          | 22851         | Starter Solenoid                | 36218         |
| Injector                       | 37091         | Stop Switch                     | 24731         |
| Injection Pump                 | 38459         | Tank, Coolant Recovery          | 24977         |
| Injection Pump (B Model)       | 43555         | Thermostat                      | 37043         |
| Injection Hardware Kit         | 37121         | Thermostat Mounting Gasket      | 36956         |
| Injector Nozzle                | 36935         | Valve Cover Gasket              | 37007         |
| Injector Return Line           | 37099         | Voltmeter                       | 37605         |
| Isolators, Front               | 24776         | Water Temperature Meter         | 37601         |
| Isolators, Rear                | 24776         | Water Temperature Sender        | 35109         |
| Manual, Operator               | 38134         | Water Temperature Switch        | 39550         |
| Manual, Parts List             | 38677         | Water Injected Exhaust Elbow 45 | 38114         |
| Manual, Technical              | 38673         | Water Injected Exhaust Elbow 90 | N/A           |
| Oil Pressure Switch            | 37323         | Zinc                            | 11885         |

## 4.4 WMD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 30594         | Oil Pressure Sender             | 24132         |
| Belt, Sea Water Pump         | N/A           | Panel, Genset Control           | 24873         |
| Belt, STD Alternator         | 30376         | Panel, Remote Stop/Start        | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch          | 24732         |
| Diode                        | 35971         | Pump, Fresh Water               | 30379         |
| Dipstick                     | 30374         | Pump, Mounting Gasket           | 30326         |
| Electronic Voltage Regulator | N/A           | Pump, Rebuild Kit               | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                 | 37431         |
| Exhaust Temperature Switch   | 30096         | Pump, Mounting Gasket           | 30326         |
| Filter, Lube Oil             | 36918         | Pump, Impeller Kit              | 34440         |
| Filter, Fuel Oil             | 30200         | Pump, Repair Kit                | 34466         |
| Filter, Electric Lift        | 30548         | Pump, Seal                      | 33043         |
| Gasket, Head                 | 30339         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan              | 30350         | Rectifier                       | 43649         |
| Gasket Set, Upper            | 30722         | Remote Lube Oil Filter          | 32149         |
| Gasket Set, Complete         | 30723         | Silencer, Air Intake            | 24920         |
| Glowplug                     | 24353         | Solenoid, Fuel Shut Off         | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat               | 24639         |
| Heat Exchanger               | 36904         | Spare Parts Kit A               | 24933         |
| Heat Exchanger End Cap       | 33297         | Spare Parts Kit B               | 24934         |
| Heat Exchanger Gasket        | 33298         | Starter Motor                   | 30593         |
| Injector                     | 30538         | Starter Solenoid                | 30245         |
| Injection Pump               | 31283         | Stop Switch                     | 24731         |
| Injection Hardware Kit       | 33093         | Tank, Coolant Recovery          | 24977         |
| Injector Nozzle              | 30297         | Thermostat                      | 24688         |
| Injector Return Line         | 30367         | Thermostat Mounting Gasket      | 24323         |
| Isolators, Front             | 24776         | Valve Cover Gasket              | 30342         |
| Isolators, Rear              | 24776         | Voltmeter                       | 37605         |
| Manual, Operator             | 35729         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 32139         | Water Temperature Sender        | 35109         |
| Manual, Technical            | 43444         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |

## 5.0 BCDA/BCDB Diesel Generator Fast Moving Parts List

| <b>Description</b>             | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|--------------------------------|---------------|---------------------------------|---------------|
| Alternator                     |               | Oil Pressure Meter              | 37603         |
| Belt, Sea Water Pump           | 30376         | Oil Pressure Sender             | 24132         |
| Belt, STD Alternator           |               | Panel, Genset Control           | 36539         |
| Circuit Breaker                | 24683         | Panel, Remote Stop/Start        | 24943         |
| Diode                          | 35971         | Preheat & Start Switch          | 24732         |
| Dipstick                       | 37072         | Pump, Fresh Water               | 37015         |
| Electronic Voltage Regulator   | 30257         | Pump, Mounting Gasket           | 36957         |
| Emergency Stop Switch          | 33259         | Pump, Rebuild Kit               | N/A           |
| Exhaust Temperature Switch     | 32923         | Pump, Sea Water                 | 33636         |
| Filter, Lube Oil               | 36918         | Pump, Mounting Gasket           | 30326         |
| Filter, Fuel Oil               | 30200         | Pump, Impeller Kit              | 34440         |
| Filter, Electric Lift          | 30548         | Pump, Repair Kit                | 34466         |
| Gasket, Head                   | 38848         | Pump, Seal                      | 33043         |
| Gasket, Head (B Model)         | 43550         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan                | 36988         | Rectifier                       | 43649         |
| Gasket Set, Upper              | 38352         | Remote Lube Oil Filter          | 40078         |
| Gasket Set, Upper (B Model)    | 43560         | Silencer, Air Intake            | 37191         |
| Gasket Set, Complete           | 38353         | Solenoid, Fuel Shut Off         | 37100         |
| Gasket Set, Complete (B Model) | 43561         | Solenoid, Preheat               | 24639         |
| Glowplug                       | 36961         | Spare Parts Kit A               | 38350         |
| Harness 15 FT. EXT 8 Pin       | 30760         | Spare Parts Kit B               | 38351         |
| Heat Exchanger                 | 38147         | Spare Parts Kit B (B Model)     | 43652         |
| Heat Exchanger End Cap         | 22850         | Starter Motor                   | 34552         |
| Heat Exchanger Gasket          | 22851         | Starter Solenoid                | 36218         |
| Injector                       | 37091         | Stop Switch                     | 24731         |
| Injection Pump                 | 38459         | Tank, Coolant Recovery          | 24977         |
| Injection Pump (B Model)       | 43555         | Thermostat                      | 37043         |
| Injection Hardware Kit         | 37121         | Thermostat Mounting Gasket      | 36956         |
| Injector Nozzle                | 36935         | Valve Cover Gasket              | 37007         |
| Injector Return Line           | 37099         | Voltmeter                       | 37605         |
| Isolators, Front               | 24776         | Water Temperature Meter         | 37601         |
| Isolators, Rear                | 24776         | Water Temperature Sender        | 35109         |
| Manual, Operator               | 38134         | Water Temperature Switch        | 39550         |
| Manual, Parts List             | 38677         | Water Injected Exhaust Elbow 45 | 38114         |
| Manual, Technical              | 38673         | Water Injected Exhaust Elbow 90 | N/A           |
| Oil Pressure Switch            | 37323         | Zinc                            | 11885         |

## 6.0 BCD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 30594         | Oil Pressure Sender             | 24132         |
| Belt, Sea Water Pump         | N/A           | Panel, Genset Control           | 24873         |
| Belt, STD Alternator         | 30592         | Panel, Remote Stop/Start        | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch          | 24732         |
| Diode                        | 35971         | Pump, Fresh Water               | 30379         |
| Dipstick                     | 30587         | Pump, Mounting Gasket           | 30326         |
| Electronic Voltage Regulator | N/A           | Pump, Rebuild Kit               | N/A           |
| Emergency Stop Switch        | 33529         | Pump, Sea Water                 | 37431         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket           | 30326         |
| Filter, Lube Oil             | 36918         | Pump, Impeller Kit              | 34440         |
| Filter, Fuel Oil             | 30200         | Pump, Repair Kit                | 40455         |
| Filter, Electric Lift        | 30548         | Pump, Seal                      | 33043         |
| Gasket, Head                 | 33786         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan              | 30498         | Rectifier                       | 43649         |
| Gasket Set, Upper            | 33775         | Remote Lube Oil Filter          | 32149         |
| Gasket Set, Complete         | 33776         | Silencer, Air Intake            | 34727         |
| Glowplug                     | 24353         | Solenoid, Fuel Shut Off         | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat               | 24639         |
| Heat Exchanger               | 33891         | Spare Parts Kit A               | 35010         |
| Heat Exchanger End Cap       | 33297         | Spare Parts Kit B               | 35011         |
| Heat Exchanger Gasket        | 33298         | Starter Motor                   | 34552         |
| Injector                     | 30538         | Starter Solenoid                | 36218         |
| Injection Pump               | 31283         | Stop Switch                     | 24731         |
| Injection Hardware Kit       | 33093         | Tank, Coolant Recovery          | 24977         |
| Injector Nozzle              | 30297         | Thermostat                      | 24688         |
| Injector Return Line         | 30367         | Thermostat Mounting Gasket      | 34196         |
| Isolators, Front             | 24776         | Valve Cover Gasket              | 30515         |
| Isolators, Rear              | 24776         | Voltmeter                       | 37605         |
| Manual, Operator             | 35729         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 32139         | Water Temperature Sender        | 35109         |
| Manual, Technical            | 43444         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |

## 7.6 BTD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 40963         | Oil Pressure Sender             | 24132         |
|                              |               | Panel, Genset Control           | 36539         |
| Belt, STD Alternator         | 45232         | Panel, Remote Stop/Start        | 36539         |
| Circuit Breaker              | 24683         | Preheat & Start Switch          | 24732         |
| Diode                        | 35931         | Pump, Fresh Water               | 37015         |
| Dipstick                     | 37072         | Pump, Mounting Gasket           | 36957         |
| Electronic Voltage Regulator | 34410         | Pump, Rebuild Kit               | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                 | 33636         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket           | 30326         |
| Filter, Lube Oil             | 36918         | Pump, Impeller Kit              | 34440         |
| Filter, Fuel Oil             | 30200         | Pump, Repair Kit                | 34466         |
| Filter, Electric Lift        | 30548         | Pump, Seal                      | 33043         |
| Gasket, Head                 | 36969         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan              | 36988         | Rectifier                       | 43649         |
| Gasket Set, Upper            | 37116         | Remote Lube Oil Filter          | 40078         |
| Gasket Set, Complete         | 37117         | Silencer, Air Intake            | 37191         |
| Glowplug                     | 36391         | Solenoid, Fuel Shut Off         | 37100         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat               | 24639         |
| Heat Exchanger               | 38147         | Spare Parts Kit A               | 41517         |
| Heat Exchanger End Cap       | 22850         | Spare Parts Kit B               | 41518         |
| Heat Exchanger Gasket        | 22851         | Starter Motor                   | 34552         |
| Injector                     | 37091         | Starter Solenoid                | 36218         |
| Injection Pump               | 37103         | Stop Switch                     | 24731         |
| Injection Hardware Kit       | 37121         | Tank, Coolant Recovery          | 24977         |
| Injector Nozzle              | 36935         | Thermostat                      | 37043         |
| Injector Return Line         | 37099         | Thermostat Mounting Gasket      | 36956         |
| Isolators, Front             | 24776         | Valve Cover Gasket              | 37007         |
| Isolators, Rear              | 24776         | Voltmeter                       | 37605         |
| Manual, Operator             | 40457         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 41800         | Water Temperature Sender        | 35109         |
| Manual, Technical            | 38673         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 38114         |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |

## 7.7 & 8.0 WMD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Oil Pressure Sender              | 24132         |
| Belt, Sea Water Pump         | N/A           | Panel, Genset Control            | 24873         |
| Belt, STD Alternator         | 30592         | Panel, Remote Stop/Start         | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch           | 24732         |
| Diode                        | N/A           | Pump, Fresh Water                | 30591         |
| Dipstick                     | 30587         | Pump, Mounting Gasket            | 30474         |
| Electronic Voltage Regulator | NA            | Pump, Rebuild Kit                | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                  | 37431         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket            | 30326         |
| Filter, Lube Oil             | 36918         | Pump, Impeller Kit               | 34440         |
| Filter, Fuel Oil             | 30200         | Pump, Repair Kit                 | 34466         |
| Filter, Electric Lift        | 30548         | Pump, Seal                       | 33043         |
| Gasket, Head                 | 30509         | Pump, Fuel Lift                  | 39275         |
| Gasket, Oil Pan              | 30498         | Rectifier                        | 43649         |
| Gasket Set, Upper            | 30726         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Complete         | 30725         | Silencer, Air Intake             | 34727         |
| Glowplug                     | 24353         | Solenoid, Fuel Shut Off          | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat                | 24639         |
| Heat Exchanger               | 24774         | Spare Parts Kit A                | 24935         |
| Heat Exchanger End Cap       | 31291         | Spare Parts Kit B                | 24936         |
| Heat Exchanger Gasket        | 31290         | Starter Motor                    | 30593         |
| Injector                     | 30538         | Starter Solenoid                 | 30245         |
| Injection Pump               | 30549         | Stop Switch                      | 24731         |
| Injection Hardware Kit       | 33093         | Tank, Coolant Recovery           | 24977         |
| Injector Nozzle              | 30297         | Thermostat                       | 24688         |
| Injector Return Line         | 30569         | Thermostat Mounting Gasket       | 24323         |
| Isolators, Front             | 21529         | Valve Cover Gasket               | 30515         |
| Isolators, Rear              | 21529         | Voltmeter                        | 37605         |
| Manual, Operator             | 32461         | Water Temperature Meter          | 37601         |
| Manual, Parts List           | 32139         | Water Temperature Sender         | 35109         |
| Manual, Technical            | 43444         | Water Temperature Switch         | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |

## 8.0 BTD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Panel, Genset Control            | 24873         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 24943         |
| Belt, STD Alternator         | 30475         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                | 30591         |
| Diode                        | 35931         | Pump, Mounting Gasket            | 30474         |
| Dipstick                     | 30587         | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                  | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 36918         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 | 30509         | Rectifier                        | 43649         |
| Gasket, Oil Pan              | 30498         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Upper            | 30724         | Silencer, Air Intake             | 34727         |
| Gasket Set, Complete         | 30725         | Solenoid, Fuel Shut Off          | 23041         |
| Glowplug                     | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A                | 35010         |
| Heat Exchanger               | 36903         | Spare Parts Kit B                | 35012         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                    | 34552         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                 | 36218         |
| Injector                     | 30538         | Stop Switch                      | 24731         |
| Injection Pump               | 30549         | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 33093         | Thermostat                       | 24688         |
| Injector Nozzle              | 30297         | Thermostat Mounting Gasket       | 34196         |
| Injector Return Line         | 34610         | Valve Cover Gasket               | 30515         |
| Isolators, Front             | 24776         | Voltmeter                        | 35111         |
| Isolators, Rear              | 24776         | Water Temperature Meter          | 35108         |
| Manual, Operator             | 36746         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 32139         | Water Temperature Switch         | 39550         |
| Manual, Technical            | 43440         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 8.0 BTDA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 43953         | Panel, Genset Control            | 36539         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 44336         |
| Belt, STD Alternator         | 45232         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                |               |
| Diode                        | 35931         | Pump, Mounting Gasket            |               |
| Dipstick                     |               | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                  | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 36918         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        |               | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 |               | Rectifier                        | 43649         |
| Gasket, Oil Pan              |               | Remote Lube Oil Filter           |               |
| Gasket Set, Upper            | 46900         | Silencer, Air Intake             |               |
| Gasket Set, Complete         | 46901         | Solenoid, Fuel Shut Off          | 37100         |
| Glowplug                     | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 44347         | Spare Parts Kit A                | 46420         |
| Heat Exchanger               | 45528         | Spare Parts Kit B                | 47157         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                 | 30245         |
| Injector                     | 37091         | Stop Switch                      | 24731         |
| Injection Pump               |               | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 46419         | Thermostat                       | 32872         |
| Injector Nozzle              |               | Thermostat Mounting Gasket       | 38225         |
| Injector Return Line         | 44500         | Valve Cover Gasket               |               |
| Isolators, Front             | 15238         | Voltmeter                        | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter          | 37601         |
| Manual, Operator             | 44800         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 48220         | Water Temperature Switch         | 39550         |
| Manual, Service              | 43440         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 10.0 BTD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Oil Pressure Sender              | 24132         |
| Belt, Sea Water Pump         | N/A           | Panel, Genset Control            | 36539         |
| Belt, STD Alternator         | 30475         | Panel, Remote Stop/Start         | 36539         |
| Circuit Breaker              | 24683         | Preheat & Start Switch           | 24732         |
| Diode                        | 35931         | Pump, Fresh Water                | 30591         |
| Dipstick                     | 30587         | Pump, Mounting Gasket            | 30474         |
| Electronic Voltage Regulator | 34410         | Pump, Rebuild Kit                | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                  | 33636         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket            | 30326         |
| Filter, Lube Oil             | 36918         | Pump, Impeller Kit               | 34440         |
| Filter, Fuel Oil             | 30200         | Pump, Repair Kit                 | 34466         |
| Filter, Electric Lift        | 30548         | Pump, Seal                       | 33043         |
| Gasket, Head                 | 37661         | Pump, Fuel Lift                  | 39275         |
| Gasket, Oil Pan              | 30498         | Rectifier                        | 43649         |
| Gasket Set, Upper            | 39730         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Complete         | 39731         | Silencer, Air Intake             | 34744         |
| Glowplug                     | 24353         | Solenoid, Fuel Shut Off          | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat                | 24639         |
| Heat Exchanger               | 36903         | Spare Parts Kit A                | 37649         |
| Heat Exchanger End Cap       | 22850         | Spare Parts Kit B                | 37650         |
| Heat Exchanger Gasket        | 22851         | Starter Motor                    | 34552         |
| Injector                     | 30538         | Starter Solenoid                 | 36218         |
| Injection Pump               | 37697         | Stop Switch                      | 24731         |
| Injection Hardware Kit       | 33093         | Tank, Coolant Recovery           | 24977         |
| Injector Nozzle              | 30297         | Thermostat                       | 24688         |
| Injector Return Line         | 30569         | Thermostat Mounting Gasket       | 34196         |
| Isolators, Front             | 24776         | Valve Cover Gasket               | 30515         |
| Isolators, Rear              | 24776         | Voltmeter                        | 37605         |
| Manual, Operator             | 36746         | Water Temperature Meter          | 37601         |
| Manual, Parts List           | 36776         | Water Temperature Sender         | 35109         |
| Manual, Technical            | 43444         | Water Temperature Switch         | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Meter           | 37603         | Water Injected. Exhaust Elbow 90 | 37401         |
| Engine, Block Assy.          | 44084         | Zinc                             | 11885         |

## 10.0 BTDA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 43953         | Panel, Genset Control            | 36539         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 44336         |
| Belt, STD Alternator         | 45232         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                |               |
| Diode                        | 35931         | Pump, Mounting Gasket            |               |
| Dipstick                     |               | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                  | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 36918         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        |               | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 |               | Rectifier                        | 43649         |
| Gasket, Oil Pan              |               | Remote Lube Oil Filter           |               |
| Gasket Set, Upper            | 46900         | Silencer, Air Intake             |               |
| Gasket Set, Complete         | 46901         | Solenoid, Fuel Shut Off          | 37100         |
| Glowplug                     | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 44347         | Spare Parts Kit A                | 46420         |
| Heat Exchanger               | 45528         | Spare Parts Kit B                | 47157         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                 | 30245         |
| Injector                     | 37091         | Stop Switch                      | 24731         |
| Injection Pump               |               | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 46419         | Thermostat                       | 32872         |
| Injector Nozzle              |               | Thermostat Mounting Gasket       | 38225         |
| Injector Return Line         | 44500         | Valve Cover Gasket               |               |
| Isolators, Front             | 15238         | Voltmeter                        | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter          | 37601         |
| Manual, Operator             | 44800         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 48220         | Water Temperature Switch         | 39550         |
| Manual, Service              | 43440         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 11.0 BTD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Panel, Genset Control            | 36539         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 36539         |
| Belt, STD Alternator         | 30475         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                | 30591         |
| Diode                        | 35931         | Pump, Mounting Gasket            | 30474         |
| Dipstick                     | 30587         | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                  | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 | 30507         | Rectifier                        | 43649         |
| Gasket, Oil Pan              | 30499         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Upper            | 37693         | Silencer, Air Intake             | 34744         |
| Gasket Set, Complete         | 37694         | Solenoid, Fuel Shut Off          | 23041         |
| Glowplug                     | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A                | 37691         |
| Heat Exchanger               | 36903         | Spare Parts Kit B                | 37692         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                 | 30245         |
| Injector                     | 30538         | Stop Switch                      | 24731         |
| Injection Pump               | 37697         | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 33093         | Thermostat                       | 24688         |
| Injector Nozzle              | 30297         | Thermostat Mounting Gasket       | 34196         |
| Injector Return Line         | 34610         | Valve Cover Gasket               | 30516         |
| Isolators, Front             | 15238         | Voltmeter                        | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter          | 37601         |
| Manual, Operator             | 36746         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 36776         | Water Temperature Switch         | 39550         |
| Manual, Technical            | 43440         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 11.0 WMD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Oil Pressure Sender              | 24132         |
| Belt, Sea Water Pump         | N/A           | Panel, Genset Control            | 24873         |
| Belt, STD Alternator         | 30592         | Panel, Remote Stop/Start         | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch           | 24732         |
| Diode                        | N/A           | Pump, Fresh Water                | 30591         |
| Dipstick                     | 30587         | Pump, Mounting Gasket            | 30474         |
| Electronic Voltage Regulator | NA            | Pump, Rebuild Kit                | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                  | 37431         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket            | 30326         |
| Filter, Lube Oil             | 36918         | Pump, Impeller Kit               | 34440         |
| Filter, Fuel Oil             | 30200         | Pump, Repair Kit                 | 34466         |
| Filter, Electric Lift        | 30548         | Pump, Seal                       | 33043         |
| Gasket, Head                 | 30507         | Pump, Fuel Lift                  | 39275         |
| Gasket, Oil Pan              | 30499         | Rectifier                        | 43649         |
| Gasket Set, Upper            | 30726         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Complete         | 30729         | Silencer, Air Intake             | 34727         |
| Glowplug                     | 24353         | Solenoid, Fuel Shut Off          | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat                | 24639         |
| Heat Exchanger               | 24774         | Spare Parts Kit A                | 24935         |
| Heat Exchanger End Cap       | 31291         | Spare Parts Kit B                | 34938         |
| Heat Exchanger Gasket        | 31290         | Starter Motor                    | 30593         |
| Injector                     | 30538         | Starter Solenoid                 | 30245         |
| Injection Pump               | 30549         | Stop Switch                      | 24731         |
| Injection Hardware Kit       | 33093         | Tank, Coolant Recovery           | 24977         |
| Injector Nozzle              | 30297         | Thermostat                       | 24688         |
| Injector Return Line         | 30569         | Thermostat Mounting Gasket       | 24323         |
| Isolators, Front             | 15238         | Valve Cover Gasket               | 30516         |
| Isolators, Rear              | 15238         | Voltmeter                        | 37605         |
| Manual, Operator             | 32461         | Water Temperature Meter          | 37601         |
| Manual, Parts List           | 32139         | Water Temperature Sender         | 35109         |
| Manual, Technical            | 43440         | Water Temperature Switch         | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |

## 12.5 BTD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Panel, Genset Control            | 24873         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 24943         |
| Belt, STD Alternator         | 30475         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                | 30473         |
| Diode                        | 35931         | Pump, Mounting Gasket            | 30474         |
| Dipstick                     | 30467         | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 30257         | Pump, Sea Water                  | 37431         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 | 30405         | Rectifier                        | 43649         |
| Gasket, Oil Pan              | 30413         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Upper            | 30728         | Silencer, Air Intake             | 31208         |
| Gasket Set, Complete         | 30729         | Solenoid, Fuel Shut Off          | 23041         |
| Glowplug                     | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A                | 24939         |
| Heat Exchanger               | 24774         | Spare Parts Kit B                | 24940         |
| Heat Exchanger End Cap       | 31291         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 31290         | Starter Solenoid                 | 30245         |
| Injector                     | 30538         | Stop Switch                      | 24731         |
| Injection Pump               | 30447         | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 33093         | Thermostat                       | 24688         |
| Injector Nozzle              | 30297         | Thermostat Mounting Gasket       | 24323         |
| Injector Return Line         | 34610         | Valve Cover Gasket               | 30497         |
| Isolators, Front             | 15238         | Voltmeter                        | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter          | 35108         |
| Manual, Operator             | 32461         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 32139         | Water Temperature Switch         | 39550         |
| Manual, Technical            | 43440         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 12.5 BTDA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Panel, Genset Control            | 36539         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 24943         |
| Belt, STD Alternator         | 30475         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                | 30591         |
| Diode                        | 35931         | Pump, Mounting Gasket            | 30474         |
| Dipstick                     | 30587         | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                  | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 | 37687         | Rectifier                        | 43649         |
| Gasket, Oil Pan              | 30499         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Upper            | 37711         | Silencer, Air Intake             | 34744         |
| Gasket Set, Complete         | 37712         | Solenoid, Fuel Shut Off          | 23041         |
| Glow plug                    | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A                | 37709         |
| Heat Exchanger               | 36903         | Spare Parts Kit B                | 37710         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                 | 30245         |
| Injector                     | 30538         | Stop Switch                      | 24731         |
| Injection Pump               | 37697         | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 33093         | Thermostat                       | 24688         |
| Injector Nozzle              | 30297         | Thermostat Mounting Gasket       | 34196         |
| Injector Return Line         | 30570         | Valve Cover Gasket               | 30516         |
| Isolators, Front             | 15238         | Voltmeter                        | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter          | 37601         |
| Manual, Operator             | 36746         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 36776         | Water Temperature Switch         | 39550         |
| Manual, Technical            | 43440         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 12.5 BTDB Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 43953         | Panel, Genset Control            | 36539         |
| Starter                      | 30593         |                                  |               |
| Belt, Sea Water Pump         | None          | Panel, Remote Stop/Start         | 44336         |
| Belt, STD Alternator         | 45232         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                | 45231         |
|                              |               | Pump, Mounting Gasket            | 30474         |
| Dipstick                     | 45230         | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                  | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 36918         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Air Intake           | 39705         | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 | 45177         | Rectifier                        | 43649         |
| Gasket, Oil Pan              | None          | Remote Lube Oil Filter           |               |
| Gasket Set, Upper            | 46902         | Silencer, Air Intake             | 43823         |
| Gasket Set, Complete         | 46903         | Solenoid, Fuel Shut Off          | 37100         |
| Glow plug                    | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 44347         | Spare Parts Kit A                | 46420         |
| Heat Exchanger               | 45528         | Spare Parts Kit B                | 47158         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                 | 30245         |
| O-Ring Exchanger End Cap     | 19321         |                                  |               |
| Injector                     | 37091         | Stop Switch                      | 24731         |
| Injection Pump               | 45265         | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 46419         | Thermostat                       | 32872         |
| Injector Nozzle              | 36935         | Thermostat Mounting Gasket       | 38225         |
| Injector Return Line         | 44496         | Transformer                      | 37463         |
| Isolators, Front             | 15238         | Valve Cover Gasket               | 45187         |
| Isolators, Rear              | 15238         | Voltmeter                        | 37605         |
| Manual, Operator             | 44800         | Water Temperature Meter          | 37601         |
| Manual, Parts List           | Not Yet       | Water Temperature Sender         | 35109         |
| Manual, Service              | 45100         | Water Temperature Switch         | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 45 | 37402         |
| Oil Pressure Meter           | 37603         | Water Injected. Exhaust Elbow 90 | 37401         |
| Oil Pressure Sender          | 24132         | Zinc                             | 11885         |

## 12.5 WMD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>               | <b>Part #</b> |
|------------------------------|---------------|----------------------------------|---------------|
| Alternator                   | 30594         | Panel, Genset Control            | 24873         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start         | 24943         |
| Belt, STD Alternator         | 30475         | Preheat & Start Switch           | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water                | 30473         |
| Diode                        | N/A           | Pump, Mounting Gasket            | 30474         |
| Dipstick                     | 30467         | Pump, Rebuild Kit                | N/A           |
| Electronic Voltage Regulator | N/A           | Pump, Sea Water                  | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket            | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit               | 34440         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                 | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                       | 33043         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                  | 39275         |
| Gasket, Head                 | 30405         | Rectifier                        | 43649         |
| Gasket, Oil Pan              | 30413         | Remote Lube Oil Filter           | 32149         |
| Gasket Set, Upper            | 30728         | Silencer, Air Intake             | 34727         |
| Gasket Set, Complete         | 30729         | Solenoid, Fuel Shut Off          | 23041         |
| Glow plug                    | 24353         | Solenoid, Preheat                | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A                | 24938         |
| Heat Exchanger               | 24774         | Spare Parts Kit B                | 24940         |
| Heat Exchanger End Cap       | 31291         | Starter Motor                    | 30593         |
| Heat Exchanger Gasket        | 31290         | Starter Solenoid                 | 30245         |
| Injector                     | 30538         | Stop Switch                      | 24731         |
| Injection Pump               | 30549         | Tank, Coolant Recovery           | 24977         |
| Injection Hardware Kit       | 33093         | Thermostat                       | 24688         |
| Injector Nozzle              | 30297         | Thermostat Mounting Gasket       | 24323         |
| Injector Return Line         | 30569         | Valve Cover Gasket               | 30497         |
| Isolators, Front             | 15238         | Voltmeter                        | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter          | 37601         |
| Manual, Operator             | 32461         | Water Temperature Sender         | 35109         |
| Manual, Parts List           | 32139         | Water Temperature Switch         | 39550         |
| Manual, Technical            | 43440         | Water Injected. Exhaust Elbow 45 | 33067         |
| Oil Pressure Switch          | 37323         | Water Injected. Exhaust Elbow 90 | N/A           |
| Oil Pressure Meter           | 37603         | Zinc                             | 11885         |
| Oil Pressure Sender          | 24132         |                                  |               |

## 15.0 BTD Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 30594         | Panel, Genset Control           | 24873         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 30475         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 34370         |
| Diode                        | 35931         | Pump, Mounting Gasket           | 34371         |
| Dipstick                     | Call WB       | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 30257         | Pump, Sea Water                 | 16423         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | 11143         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 33104         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                | 18172         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 24831         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 34283         | Rectifier                       | 43649         |
| Gasket, Oil Pan              | Call WB       | Remote Lube Oil Filter          | 32149         |
| Gasket Set, Upper            | 34443         | Silencer, Air Intake            | 34021         |
| Gasket Set, Complete         | 34442         | Solenoid, Fuel Shut Off         | 23041         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 33444         |
| Heat Exchanger               | 36898         | Spare Parts Kit B               | 34445         |
| Heat Exchanger End Cap       | 31291         | Starter Motor                   | 30593         |
| Heat Exchanger Gasket        | 31290         | Starter Solenoid                | 30245         |
| Injector                     | 34376         | Stop Switch                     | 24731         |
| Injection Pump               | 37760         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 34441         | Thermostat                      | 24688         |
| Injector Nozzle              | 34377         | Thermostat Mounting Gasket      | 33966         |
| Injector Return Line         | 34857         | Valve Cover Gasket              | 34296         |
| Isolators, Front             | 15238         | Voltmeter                       | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter         | 35108         |
| Manual, Operator             | 36856         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 34908         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 34907         | Water Injected Exhaust Elbow 45 | 33067         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 | N/A           |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 15.0 BTDA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 39790         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 11672         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32213         |
| Diode                        | 35931         | Pump, Mounting Gasket           | 31036         |
| Dipstick                     | 30991         | Pump, Rebuild Kit               | 31054         |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                 | 16423         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | 11143         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 33104         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                | 18172         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 18159         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 30987         | Rectifier                       | 43649         |
| Gasket, Oil Pan              | 31051         | Remote Lube Oil Filter          | 32149         |
| Gasket Set, Upper            | 38773         | Silencer, Air Intake            | 37786         |
| Gasket Set, Complete         | 38774         | Solenoid, Fuel Shut Off         | 24338         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 38775         |
| Heat Exchanger               | 38300         | Spare Parts Kit B               | 38776         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 30245         |
| Injector                     | 32743         | Stop Switch                     | 24731         |
| Injection Pump               | 36193         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 32050         | Thermostat                      | 24690         |
| Injector Nozzle              | 32477         | Thermostat Mounting Gasket      | 33373         |
| Injector Return Line         | 31020         | Valve Cover Gasket              | 30516         |
| Isolators, Front             | 15238         | Voltmeter                       | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 38663         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 38824         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 32460         | Water Injected Exhaust Elbow 45 |               |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 15.0 BTDB Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 39790         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start        | 42448         |
| Belt, STD Alternator         | 11672         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32213         |
| Diode                        | 35931         | Pump, Mounting Gasket           | 31036         |
| Dipstick                     | 40940         | Pump, Rebuild Kit               | 31054         |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                 | 16423         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | 11143         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 33104         |
| Filter, Lube Oil             | 35828         | Pump, Repair Kit                | 18172         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 18159         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 43180         | Rectifier                       | 43649         |
| Gasket, Oil Pan              | 43213         | Remote Lube Oil Filter          | 32149         |
| Gasket Set, Upper            | 41787         | Silencer, Air Intake            | 37786         |
| Gasket Set, Complete         | 41788         | Solenoid, Fuel Shut Off         | 24338         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 38775         |
| Heat Exchanger               | 38300         | Spare Parts Kit B               | 41786         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 30245         |
| Injector                     | 43211         | Stop Switch                     | 24731         |
| Injection Pump               | 43183         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 32050         | Thermostat                      | 24690         |
| Injector Nozzle              | 43212         | Thermostat Mounting Gasket      | 33373         |
| Injector Return Line         | 31020         | Valve Cover Gasket              | 30516         |
| Isolators, Front             | 15238         | Voltmeter                       | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 38663         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 38824         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 32460         | Water Injected Exhaust Elbow 45 |               |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 15.0 BTDC Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 43953         | Panel, Genset Control           | 36539         |
| Starter                      | 30593         |                                 |               |
| Belt, Sea Water Pump         | None          | Panel, Remote Stop/Start        | 44336         |
| Belt, STD Alternator         | 45232         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 45231         |
|                              |               | Pump, Mounting Gasket           | 30474         |
| Dipstick                     | 45230         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 34410         | Pump, Sea Water                 | 33636         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | 30326         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 34440         |
| Filter, Lube Oil             | 36918         | Pump, Repair Kit                | 34466         |
| Filter, Fuel Oil             | 30200         | Pump, Seal                      | 33043         |
| Filter, Air Intake           | 39705         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 45177         | Rectifier                       | 43649         |
| Gasket, Oil Pan              | None          | Remote Lube Oil Filter          |               |
| Gasket Set, Upper            | 46902         | Silencer, Air Intake            | 43823         |
| Gasket Set, Complete         | 46903         | Solenoid, Fuel Shut Off         | 37100         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 44347         | Spare Parts Kit A               | 46420         |
| Heat Exchanger               | 45528         | Spare Parts Kit B               | 47158         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 30593         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 30245         |
| O-Ring Exchanger End Cap     | 19321         |                                 |               |
| Injector                     | 37091         | Stop Switch                     | 24731         |
| Injection Pump               | 45265         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 46419         | Thermostat                      | 32872         |
| Injector Nozzle              | 36935         | Thermostat Mounting Gasket      | 38225         |
| Injector Return Line         | 44496         | Transformer                     | 37463         |
| Isolators, Front             | 15238         | Valve Cover Gasket              | 45187         |
| Isolators, Rear              | 15238         | Voltmeter                       | 37605         |
| Manual, Operator             | 44800         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 47631         | Water Temperature Sender        | 35109         |
| Manual, Service              | 45100         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 37402         |
| Oil Pressure Meter           | 37603         | Water Injected Exhaust Elbow 90 | 37401         |
| Oil Pressure Sender          | 24132         | Zinc                            | 11885         |

## 15.0 WTA - WMF Diesel Generators Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Panel, Genset Control           | 33348         |
| Belt, Sea Water Pump         | N/A           | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 16001         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32213         |
| Diode                        | 43649         | Pump, Mounting Gasket           | 31035         |
| Dipstick                     | 30991         | Pump, Rebuild Kit               | 31054         |
| Electronic Voltage Regulator | N/A           | Pump, Sea Water                 | 16423         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | 11143         |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 33104         |
| Filter, Lube Oil             | 16655         | Pump, Repair Kit                | 18172         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 18159         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 30897         | Rectifier                       | 43649         |
| Gasket, Oil Pan              | 31051         | Remote Lube Oil Filter          | 21513         |
| Gasket Set, Upper            | 32051         | Silencer, Air Intake            | 37786         |
| Gasket Set, Complete         | 32082         | Solenoid, Fuel Shut Off         | 23041         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 32058         |
| Heat Exchanger               | 36905         | Spare Parts Kit B               | 32053         |
| Heat Exchanger End Cap       | 31291         | Starter Motor                   | 23953         |
| Heat Exchanger Gasket        | 31290         | Starter Solenoid                | 23338         |
| Injector                     | 32743         | Stop Switch                     | 24731         |
| Injection Pump               | 32509         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 32050         | Thermostat                      | 24690         |
| Injector Nozzle              | 32744         | Thermostat Mounting Gasket      | 33373         |
| Injector Return Line         | 34857         | Valve Cover Gasket              | 30984         |
| Isolators, Front             | 32013         | Voltmeter                       | 23090         |
| Isolators, Rear              | 32013         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 33533         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 32416         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 32460         | Water Injected Exhaust Elbow 45 | 33067         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 | N/A           |
| Oil Pressure Meter           | 24133         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 20.0 BED Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 39790         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | 31152         | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 39181         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32711         |
| Diode                        | 39666         | Pump, Mounting Gasket           | 32712         |
| Dipstick                     | 32646         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 39640         | Pump, Sea Water                 | 38445         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | N/A           |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 11907         |
| Filter, Lube Oil             | 40154         | Pump, Repair Kit                | 33329         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 14774         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 32641         | Rectifier                       | N/A           |
| Gasket, Oil Pan              | 32716         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Upper            | 39675         | Silencer, Air Intake            | 37450         |
| Gasket Set, Complete         | 39676         | Solenoid, Fuel Shut Off         | 41372         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 39326         |
| Heat Exchanger               | 38300         | Spare Parts Kit B               | 39327         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 38384         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 39523         |
| Injector                     | 32743         | Stop Switch                     | 24731         |
| Injection Pump               | 32748         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 33094         | Thermostat                      | 24690         |
| Injector Nozzle              | 32744         | Thermostat Mounting Gasket      | 33373         |
| Injector Return Line         | 32745         | Valve Cover Gasket              | 32639         |
| Isolators, Front             | 15238         | Voltmeter                       | 37605         |
| Isolators, Rear              | 15238         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 39685         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 40000         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 40485         | Water Injected Exhaust Elbow 45 | 38760         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 20.0 BEDA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 39790         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | 31152         | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 39181         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32711         |
| Diode                        | 39666         | Pump, Mounting Gasket           | 41367         |
| Dipstick                     | 41351         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 39640         | Pump, Sea Water                 | 38445         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | N/A           |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 11907         |
| Filter, Lube Oil             | 40154         | Pump, Repair Kit                | 33329         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 14774         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 41348         | Rectifier                       | N/A           |
| Gasket, Oil Pan              | 32716         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Upper            | 41392         | Silencer, Air Intake            | 37783         |
| Gasket Set, Complete         | 41393         | Solenoid, Fuel Shut Off         | 41372         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 41396         |
| Heat Exchanger               | 38300         | Spare Parts Kit B               | 41397         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 38384         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 39523         |
| Injector                     | 41367         | Stop Switch                     | 24731         |
| Injection Pump               | 41370         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 41394         | Thermostat                      | 24960         |
| Injector Nozzle              | 41368         | Thermostat Mounting Gasket      | 33373         |
| Injector Return Line         | 32745         | Valve Cover Gasket              | 32639         |
| Isolators, Front             | 15238         | Voltmeter                       | 37605         |
| Isolators, Rear              | 15239         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 39685         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 42000         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 43317         | Water Injected Exhaust Elbow 45 | 38760         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 20.0 WTA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Oil Pressure Sender             | 33348         |
| Belt, Sea Water Pump         | 31152         | Panel, Genset Control           | 24873         |
| Belt, STD Alternator         | 11672         | Panel, Remote Stop/Start        | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch          | 24732         |
| Diode                        | 43649         | Pump, Fresh Water               | 24557         |
| Dipstick                     | 24608         | Pump, Mounting Gasket           | 24473         |
| Electronic Voltage Regulator | 30257         | Pump, Rebuild Kit               | 24538         |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                 | 24102         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket           | N/A           |
| Filter, Lube Oil             | 16655         | Pump, Impeller Kit              | 33112         |
| Filter, Fuel Oil             | 24363         | Pump, Repair Kit                | 24652         |
| Filter, Electric Lift        | 30548         | Pump, Seal                      | 24649         |
| Gasket, Head                 | 24344         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan              | 24156         | Rectifier                       | 43649         |
| Gasket Set, Upper            | 24575         | Remote Lube Oil Filter          | 21513         |
| Gasket Set, Complete         | 24576         | Silencer, Air Intake            | 31321         |
| Glow plug                    | 24353         | Solenoid, Fuel Shut Off         | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat               | 24639         |
| Heat Exchanger               | 36889         | Spare Parts Kit A               | 24572         |
| Heat Exchanger End Cap       | 22850         | Spare Parts Kit B               | 24573         |
| Heat Exchanger Gasket        | 22851         | Starter Motor                   | 23953         |
| Injector                     | 24562         | Starter Solenoid                | 23338         |
| Injection Pump               | 31286         | Stop Switch                     | 24731         |
| Injection Hardware Kit       | 24574         | Tank, Coolant Recovery          | 24977         |
| Injector Nozzle              | 24565         | Thermostat                      | 24690         |
| Injector Return Line         | 20950         | Thermostat Mounting Gasket      | 33373         |
| Isolators, Front             | 21529         | Valve Cover Gasket              | 24343         |
| Isolators, Rear              | 21529         | Voltmeter                       | 23090         |
| Manual, Operator             | 33533         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 32416         | Water Temperature Sender        | 35109         |
| Manual, Technical            | 32460         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter           | 24133         | Zinc                            | 11885         |

## 25.0 BED Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 39790         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | 31152         | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 39181         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32711         |
| Diode                        | 39666         | Pump, Mounting Gasket           | 32712         |
| Dipstick                     | 32646         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 39640         | Pump, Sea Water                 | 38445         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | N/A           |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 11907         |
| Filter, Lube Oil             | 40154         | Pump, Repair Kit                | 33329         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 14774         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 32641         | Rectifier                       | N/A           |
| Gasket, Oil Pan              | 32716         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Upper            | 39675         | Silencer, Air Intake            | 37450         |
| Gasket Set, Complete         | 39676         | Solenoid, Fuel Shut Off         | 24338         |
| Glow plug                    | 24353         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 39326         |
| Heat Exchanger               | 38300         | Spare Parts Kit B               | 39327         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 38384         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 39523         |
| Injector                     | 32743         | Stop Switch                     | 24731         |
| Injection Pump               | 32748         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 33094         | Thermostat                      | 24960         |
| Injector Nozzle              | 32744         | Thermostat Mounting Gasket      | 33373         |
| Injector Return Line         | 32745         | Valve Cover Gasket              | 32639         |
| Isolators, Front             | 15238         | Voltmeter                       | 37605         |
| Isolators, Rear              | 15239         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 39685         | Water Temperature Sender        | 35109         |
| Manual, Parts List           | 40000         | Water Temperature Switch        | 39550         |
| Manual, Technical            | 40485         | Water Injected Exhaust Elbow 45 | 38760         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 25.0 WTA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Oil Pressure Sender             | 33348         |
| Belt, Sea Water Pump         | 16446         | Panel, Genset Control           | 24873         |
| Belt, STD Alternator         | 32977         | Panel, Remote Stop/Start        | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch          | 24732         |
| Diode                        | 43649         | Pump, Fresh Water               | 32711         |
| Dipstick                     | 32646         | Pump, Mounting Gasket           | 32712         |
| Electronic Voltage Regulator | 30257         | Pump, Rebuild Kit               | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                 | 13353         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket           | N/A           |
| Filter, Lube Oil             | 40154         | Pump, Impeller Kit              | 11907         |
| Filter, Fuel Oil             | 24363         | Pump, Repair Kit                | 33329         |
| Filter, Electric Lift        | 30548         | Pump, Seal                      | 14774         |
| Gasket, Head                 | 32716         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan              | 32716         | Rectifier                       | 43649         |
| Gasket Set, Upper            | 32555         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Complete         | 32556         | Silencer, Air Intake            | 37450         |
| Glow plug                    | 24353         | Solenoid, Fuel Shut Off         | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat               | 24639         |
| Heat Exchanger               | 36889         | Spare Parts Kit A               | 32557         |
| Heat Exchanger End Cap       | 22850         | Spare Parts Kit B               | 32558         |
| Heat Exchanger Gasket        | 22851         | Starter Motor                   | 23953         |
| Injector                     | 32743         | Starter Solenoid                | 23338         |
| Injection Pump               | 32729         | Stop Switch                     | 24731         |
| Injection Hardware Kit       | 33094         | Tank, Coolant Recovery          | 24977         |
| Injector Nozzle              | 32744         | Thermostat                      | 24690         |
| Injector Return Line         | 20950         | Thermostat Mounting Gasket      | 33373         |
| Isolators, Front             | 15239         | Valve Cover Gasket              | 24343         |
| Isolators, Rear              | 15239         | Voltmeter                       | 23090         |
| Manual, Operator             | 33533         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 33620         | Water Temperature Sender        | 35109         |
| Manual, Technical            | 33355         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 33067         |
| Oil Pressure Meter           | 24133         | Zinc                            | 11885         |

## 32.0 BED Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | 13810         | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 32544         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32711         |
| Diode                        | 39666         | Pump, Mounting Gasket           | 40363         |
| Dipstick                     | 32759         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 39640         | Pump, Sea Water                 | 38445         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | N/A           |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 11907         |
| Filter, Lube Oil             | 40154         | Pump, Repair Kit                | 33329         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 14774         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39475         |
| Gasket, Head                 | 32818         | Rectifier                       | N/A           |
| Gasket, Oil Pan              | 32790         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Upper            |               | Silencer, Air Intake            | 37782         |
| Glow plug                    | 24353         | Solenoid, Fuel Shut Off         | 24338         |
| Heater, Air Intake           | 40368         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 39945         |
| Heat Exchanger               | 39230         | Spare Parts Kit B               | 40405         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 38384         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 39523         |
| Injector                     | 24563         | Stop Switch                     | 24731         |
| Injection Pump               | 32894         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 33095         | Thermostat                      | 32872         |
| Injector Nozzle              | 24565         | Thermostat Mounting Gasket      | 38225         |
| Injector Return Line         |               | Valve Cover Gasket              | 32755         |
| Isolators, Front             |               | Voltmeter                       | 37605         |
| Isolators, Rear              |               | Water Temperature Meter         | 37601         |
| Manual, Operator             | 39837         | Water Temperature Sender        | 35109         |
| Manual, Parts List           |               | Water Temperature Switch        | 39550         |
| Manual, Technical            |               | Water Injected Exhaust Elbow 45 | 38760         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 32.0 BEDA Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | 13810         | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 32544         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 40362         |
| Diode                        | 39666         | Pump, Mounting Gasket           | 40363         |
| Dipstick                     | 32759         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 39640         | Pump, Sea Water                 | 38445         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | N/A           |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 11907         |
| Filter, Lube Oil             | 40154         | Pump, Repair Kit                | 33329         |
| Filter, Fuel Oil             | 14776         | Pump, Seal                      | 14774         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 41443         |
| Gasket, Head                 | 32818         | Rectifier                       | N/A           |
| Gasket, Oil Pan              | 32790         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Upper            |               | Silencer, Air Intake            | 37782         |
| Gasket Set, Complete         |               | Solenoid, Fuel Shut Off         | 24338         |
| Heater, Air Intake           | 40368         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 40387         |
| Heat Exchanger               | 39230         | Spare Parts Kit B               | 40388         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 38384         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 39523         |
| Injector                     | 24563         | Stop Switch                     | 24731         |
| Injection Pump               | 32894         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 33095         | Thermostat                      | 32872         |
| Injector Nozzle              | 24565         | Thermostat Mounting Gasket      | 38225         |
| Injector Return Line         |               | Valve Cover Gasket              | 32755         |
| Isolators, Front             | 301136        | Voltmeter                       | 37605         |
| Isolators, Rear              | 15239         | Water Temperature Meter         | 37601         |
| Manual, Operator             | 39837         | Water Temperature Sender        | 35109         |
| Manual, Parts List           |               | Water Temperature Switch        | 39550         |
| Manual, Technical            |               | Water Injected Exhaust Elbow 45 | 38760         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 32.0 BEDB Diesel Generator Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Panel, Genset Control           | 36539         |
| Belt, Sea Water Pump         | 13810         | Panel, Remote Stop/Start        | 24943         |
| Belt, STD Alternator         | 32544         | Preheat & Start Switch          | 24732         |
| Circuit Breaker              | 24683         | Pump, Fresh Water               | 32711         |
| Diode                        | 39666         | Pump, Mounting Gasket           | 32712         |
| Dipstick                     | 32759         | Pump, Rebuild Kit               | N/A           |
| Electronic Voltage Regulator | 39640         | Pump, Sea Water                 | 38445         |
| Emergency Stop Switch        | 33259         | Pump, Mounting Gasket           | N/A           |
| Exhaust Temperature Switch   | 32923         | Pump, Impeller Kit              | 11907         |
| Filter, Lube Oil             | 40154         | Pump, Repair Kit                | 33329         |
| Filter, Fuel Oil             | 24363         | Pump, Seal                      | 14774         |
| Filter, Electric Lift        | 30548         | Pump, Fuel Lift                 | 39275         |
| Gasket, Head                 | 32818         | Rectifier                       | N/A           |
| Gasket, Oil Pan              | 32790         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Upper            |               | Silencer, Air Intake            | 37782         |
| Glow plug                    | 24353         | Solenoid, Fuel Shut Off         | 24338         |
| Heater, Air Intake           | 40368         | Solenoid, Preheat               | 24639         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Spare Parts Kit A               | 39945         |
| Heat Exchanger               | 39230         | Spare Parts Kit B               | 40741         |
| Heat Exchanger End Cap       | 22850         | Starter Motor                   | 38384         |
| Heat Exchanger Gasket        | 22851         | Starter Solenoid                | 39523         |
| Injector                     | 24563         | Stop Switch                     | 24731         |
| Injection Pump               | 32894         | Tank, Coolant Recovery          | 24977         |
| Injection Hardware Kit       | 33095         | Thermostat                      | 32872         |
| Injector Nozzle              | 24565         | Thermostat Mounting Gasket      | 38225         |
| Injector Return Line         |               | Valve Cover Gasket              | 32755         |
| Isolators, Front             |               | Voltmeter                       | 37605         |
| Isolators, Rear              |               | Water Temperature Meter         | 37601         |
| Manual, Operator             | 39837         | Water Temperature Sender        | 35109         |
| Manual, Parts List           |               | Water Temperature Switch        | 39550         |
| Manual, Technical            |               | Water Injected Exhaust Elbow 45 | 38760         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 90 |               |
| Oil Pressure Meter           | 37603         | Zinc                            | 11885         |
| Oil Pressure Sender          | 24132         |                                 |               |

## 32.0 WTA - WMF Diesel Generators Fast Moving Parts List

| <b>Description</b>           | <b>Part #</b> | <b>Description</b>              | <b>Part #</b> |
|------------------------------|---------------|---------------------------------|---------------|
| Alternator                   | 24684         | Oil Pressure Sender             | 33348         |
| Belt, Sea Water Pump         | 11400         | Panel, Genset Control           | 24873         |
| Belt, STD Alternator         | 32544         | Panel, Remote Stop/Start        | 24943         |
| Circuit Breaker              | 24683         | Preheat & Start Switch          | 24732         |
| Diode                        | 43649         | Pump, Fresh Water               | 32895         |
| Dipstick                     | 32759         | Pump, Mounting Gasket           | 32855         |
| Electronic Voltage Regulator | 30257         | Pump, Rebuild Kit               | N/A           |
| Emergency Stop Switch        | 33259         | Pump, Sea Water                 | 13353         |
| Exhaust Temperature Switch   | 32923         | Pump, Mounting Gasket           | N/A           |
| Filter, Lube Oil             | 32874         | Pump, Impeller Kit              | 11907         |
| Filter, Fuel Oil             | 24363         | Pump, Repair Kit                | 33329         |
| Filter, Electric Lift        | 30548         | Pump, Seal                      | 14774         |
| Gasket, Head                 | 32818         | Pump, Fuel Lift                 | 39275         |
| Gasket, Oil Pan              | 32790         | Rectifier                       | 43649         |
| Gasket Set, Upper            | 32559         | Remote Lube Oil Filter          | 32973         |
| Gasket Set, Complete         | 32560         | Silencer, Air Intake            | 32164         |
| Glow plug                    | 24353         | Solenoid, Fuel Shut Off         | 23041         |
| Harness 15 FT. EXT 8 Pin     | 30760         | Solenoid, Preheat               | 24639         |
| Heat Exchanger               | 36890         | Spare Parts Kit A               | 32561         |
| Heat Exchanger End Cap       | 33299         | Spare Parts Kit B               | 32562         |
| Heat Exchanger Gasket        | 33000         | Starter Motor                   | 31226         |
| Injector                     | 24563         | Starter Solenoid                | 23338         |
| Injection Pump               | 32808         | Stop Switch                     | 24731         |
| Injection Hardware Kit       | 33095         | Tank, Coolant Recovery          | 24977         |
| Injector Nozzle              | 24565         | Thermostat                      | 32872         |
| Injector Return Line         | 20950         | Thermostat Mounting Gasket      | 32153         |
| Isolators, Front             | 15239         | Valve Cover Gasket              | 32755         |
| Isolators, Rear              | 15239         | Voltmeter                       | 23090         |
| Manual, Operator             | 33533         | Water Temperature Meter         | 37601         |
| Manual, Parts List           | 33620         | Water Temperature Sender        | 35109         |
| Manual, Technical            | 33355         | Water Temperature Switch        | 39550         |
| Oil Pressure Switch          | 37323         | Water Injected Exhaust Elbow 45 | 33531         |
| Oil Pressure Meter           | 24133         | Zinc                            | 11885         |

## Century Series Diesel Generators Fast Moving Parts List

| Description                   | 4 Cyl | 6 Cyl | Description                            | 4 Cyl  | 6 Cyl |
|-------------------------------|-------|-------|--|--------|-------|
| Alternator, 12V 50A-24V 42A   | 39139 |       | Oil Pressure Sender 12V                | 24132  |       |
| Alternator, 24V 42A           | 38530 |       | Oil Pressure Sender 24V                | 42161  |       |
| Belt, Guard                   | 44044 |       | Panel Kit, Admiral 12V                 | 36842  |       |
| Belt, Water Pump - Alternator | 44385 |       | Panel Kit, Admiral 24V                 | 46637  |       |
| Circuit Breaker 20A 12VDC     | 24683 |       | Panel, Genset Control 12V              | 36539  |       |
| Circuit Breaker 10A 24VDC     | 20946 |       | Panel, Genset Control 24V              | 42162  |       |
| Dipstick                      | 43577 |       | Panel, Remote Start/Stop 15 Pin        | 44336  |       |
| Emergency Stop Switch         | 33259 |       | Pump, Fresh Water                      |        |       |
| Exhaust Temperature Switch    | 32923 |       | Pump, Mounting Gasket                  |        |       |
| Filter, Air                   | 43930 |       | Pump, Rebuild Kit                      |        |       |
| Filter, Fuel Oil              | 46140 | 46146 | Pump, Sea Water                        | 43514  |       |
| Filter, Lube Oil              | 44995 | 44998 | Pump, Mounting O-Ring                  | 44183  |       |
| Fuse 8 AMP                    | 33769 |       | Pump, Impeller Kit                     |        |       |
| Gasket, Head                  |       |       | Pump, Repair Kit                       |        |       |
| Gasket, Oil Pan               | 45444 | 45445 | Remote Lube Oil Filter                 | 44995  | 44998 |
| Gasket Set, Upper             |       |       | Solenoid, Fuel Control 12V             | 303007 |       |
| Gasket Set, Complete          |       |       | Solenoid, Fuel Control 24V             | 39746  |       |
| Glow plug                     | 45124 |       | Solenoid, Fuel Stop 12V                | 45561  |       |
| Harness Ext 15 Pin 15'-30'    | 44347 | 44799 | Solenoid, Fuel Stop 24V                | 45562  |       |
| Harness 15 FT. EXT 8 Pin      | 30760 |       | Solenoid, Preheat 12V                  | 24639  |       |
| Harness 15 FT. EXT 4 Pin      | 36557 |       | Solenoid, Preheat 24V                  | 22249  |       |
| Heat Exchanger                | 44791 | 44792 | Spare Parts Kit A                      |        |       |
| Heat Exchanger O-Ring         | 44131 |       | Spare Parts Kit B                      |        |       |
| Heat Exchanger End Cap        | 42053 |       | Starter Motor 12V-24V                  | 43472  | 39417 |
| Heat Exchanger Gasket         | 42054 |       | Switch, Preheat & Start                | 24732  |       |
| Hourmeter                     | 36192 | 42159 | Switch, Stop                           | 24731  |       |
| Injector                      |       |       | Tachometer, Admiral Panel              | 39826  |       |
| Injection Pump                |       |       | Tank, Coolant Recovery                 | 24977  |       |
| Injection Hardware Kit        |       |       | Thermostat                             | 45486  |       |
| Injector Nozzle               |       |       | Thermostat Mounting Gasket             | 42042  |       |
| Injector Return Line          |       |       | Valve Cover Gasket                     |        |       |
| Isolator, Front               | 40513 | 40513 | Voltage Regulator                      |        |       |
| Isolators, Rear               | 40512 | 40513 | Voltmeter                              | 35111  | 42156 |
| Manual, Operator              | 45139 |       | Water Temperature Meter 12V-24V        | 35108  |       |
| Manual, Technical             |       |       | Water Temperature Meter 12V-24V        | 42158  |       |
| Oil Cooler                    | 36650 |       | Water Temperature Switch               | 39550  |       |
| Oil Pressure Switch #5        | 37323 |       | Water Injected Exhaust Elbow Turbo     | 44493  |       |
| Oil Pressure Switch #10       | 11552 |       | Water Injected Exhaust Elbow Nat. Asp. | 44495  |       |
| Oil Pressure Meter 12V        | 35110 |       | Wiring Harness                         | 44782  |       |
| Oil Pressure Meter 24V        | 42157 |       | Zinc                                   | 11885  |       |